



# Samsung VR4607 belt Replacement

Written By: unsubstantiated

## INTRODUCTION

A worn-out belt is not strong enough to fast wind, or not strong enough even to play. Belt might be broken.



### TOOLS:

- [cruciform turnscrew](#) (1)

*Screw bosses are plastic, high torque is not involved, so fit is not important. Drives like phillips, JIS, pozidriv seem to work. Shaft can be any length.*

- [Slotted Screwdriver](#) (1)

*or fingernail or wooden stick or other, just to lift plastic tabs*



### PARTS:

- [drive-belt](#) (1)

**square belt, circumference 10,688 inch, thickness 0,079 inch**

## Step 1 — bottom screws



- three identical screws, shaft length ?

## Step 2 — cover



- three identical screws, shaft length ?
- Cover lifts away. One may call it 'top cover'.

### Step 3 — face



- Lift four top tabs and two bottom tabs to remove face. If your fingers are not strong enough, then use any tool to prise (such as table knife or slotted screwdriver).

### Step 4 — transport



- Insert wisdom here.

## Step 5 — belt



- Replace capstan/idler/drive belt.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 04:02:10 PM.